


## FEATURES AND SPECIFICATIONS

### RY2129 ACCELERATE



#### BUTTON OPERATION:

**A:** RESET **B:** MODE **C:** LIGHT **D:** START/STOP

# ROOTS

## Operating Instructions

### RY2129 ACCELERATE

www.watchroots.com

© ROOTS IS A REGISTERED TRADE MARK OF ROOTS CANADA LTD. USED UNDER LICENSE  
COSMOON CORPORATION IS A LICENSEE OF ROOTS CANADA LTD.

# ROOTS

## Mode d'emploi

### RY2129 ACCELERATE

www.watchroots.com


© ROOTS EST UNE MARQUE DÉPOSÉE DE ROOTS CANADA LTD. UTILISÉE SOUS LICENCE  
COSMOON CORPORATION EST UN LICENCIÉ DE ROOTS CANADA LTD.

## Features:

- Standard display mode: Hour, Minutes, Seconds, Month, Date, Day of the week, AM/PM.
- Functions:
  - Chronograph
  - Timer
  - Second Time Zone
  - Alarm function with buzzer signal output
  - Hourly chime
  - 12/24 hour switch option
  - Electro-luminescent back light
- Accuracy at normal temperature (25°C): ±30 seconds a month
- Normal operation temperature range: 10°C to 40°C
- Battery: CR2025(Digital), UC377(Analogue)


## CHANGING THE MODE

The MODE will be change each time the 'B' button is pressed respectively. Sequence will be:



## TIME SETTING

- In NORMAL TIME MODE press the A button for 2 seconds to enter the TIME SETTING MODE. The seconds will be blinking simultaneously.
- Press the D button to reset the seconds.
- Press the B button to advance to the next item. Setting sequence will be:



- Press the D button to adjust the setting.
- Press the A button at anytime to return to the NORMAL TIME MODE.

## HOW TO SET COUNT DOWN TIMER

- In TIMER MODE, press the A button to enter the TIMER SETTING MODE. The seconds will be blinking.
- Press the D button to adjust the setting.
- Press the B button to advance to next setting. Setting sequence will be:




- Press the A button to exiting the SETTING MODE.

## HOW TO USE COUNT DOWN TIMER

- In COUNT DOWN TIMER MODE press the D button to start counting.
- Press the D button at anytime to stop counting.
- When the timer has counted down to zero, a 60 seconds beep sound will be activated.
- Press the A, B or D button to stop the beep sound.

## HOW TO SET SECOND TIME ZONE

- In SECOND TIME ZONE MODE press the A button to enter the SECOND TIME ZONE SETTING MODE. The hour will be blinking.
- Press the D button to adjust the setting item.
- Press B button to advance to next setting. Setting sequence will be:



- Press the A button to exit the SETTING MODE.

## CHRONOGRAPH SETTING


### SIMPLE COUNTING

- In CHRONOGRAPH MODE, press the D button to start counting.
- Press the D button again to stop the counting.
- Press the A button to reset to '0'.




### LAP COUNTING

- Follow the same operation as above to start counting.
- Press the A button to read the first lap, counting will continue internally.
- Press the A button again to resume the counting.
- Press the A button again to read the second lap.
- Repeat the above operation will split time.
- To read the final count, press the D button to stop the counting.
- Press the A button to reset to '0'.



## HOW TO SET THE ALARM

- In ALARM MODE press the A button to enter the ALARM TIME SETTING MODE, 'Hour' will be blinking.
- Press the D button to adjust the setting.
- Press the B button to advance to next setting. Setting sequence will be:



- Press the A button to exit the SETTING MODE.

## ALARM ON/OFF

- In ALARM TIME MODE press the D button to enable or disable the alarm ON/OFF.
- Press the A, B or D button to stop the Alarm.

## CHIME ON/OFF

In NORMAL TIME MODE press the D button to enable or disable the chime.

## EL BACK LIGHT

Press the C button, the EL back light will be on for 3 seconds.